

PRO BAG 3 / PRO BAG 4




PRO Bag 3

PRO Bag 4



DELSEY



Hide-a-way handles

Clever design produces a style so streamlined you'll need to look twice to see just how these handles stow away.



Front Organizer

A home for every business essential in the maxi-room, multi-pocketed front organizer section.

PRO Bag 3

Customizable interior with room for:

2 Pro SLR's with attached lenses, 4 to 5 additional lenses, Pro Flash, Light Meter, many more accessories & zippered top mesh pocket.

PRO Bag 4


Customizable interior with room for:

Pro SLR with attached lens, additional lenses, Pro Flash, Light Meter, many more accessories & zippered top mesh pocket.

Features:

- Front Organizer Section
- Two Side Pockets
- Detachable Film Pouch*
- Hide-a-way handles
- Tripod carry system
- Padded shoulder strap
- Padlock
- Airline carry-on

* PRO Bag 3 only



Dimensions (cm)		PRO Bag 3	PRO Bag 4
Internal	Length	30	28
	Height	19	17
	Depth	22	20
External	Length	42	32,5
	Height	20	20
	Depth	28	25,5
Weight (gr)		2,030	1,350
Colour		Order Code	Order Code
Black		DELPROBAG3	DELPROBAG4

Airline carry-on size regulations do change. Please check with your carrier before departure.